


360° HD Wi-Fi CAMERA



- 1. Photoresistor
- 2. Lens
- 3. Indicator light
- 4. Infrared night vision light
- 5. Reset
- 6. microSD card slot
- 7. Antenna
- 8. LAN port
- 9. Micro USB power port
- 10. Screw hole

Thanks for purchasing your very own 360° HD Wi-Fi Camera! Please read through the following instructions carefully before using your camera to ensure effective usage.

Important Information Before Use

1. The HD Wi-Fi Camera can only be used for the intended purpose according to the instructions.
2. Do not submerge in water; wipe clean with damp cloth only.
3. Do not leave in direct sunlight.

Setting Up Your 360° HD Wi-Fi Camera

Note: You must have Android version 4.1 or iOS 9.2 or later to use this app.



Step 1: 3 ways to download the app.

1. Go to s.360eye.cc
2. Use the QR code provided
3. Search for 360eyes in the App Store or Google Play Store.






Step 2: Register the App and Connect the Camera

1. Register the app using your email address.
2. You will be sent a verification code via email. Enter this to get started.





Step 3: Connect the Camera Using a Wireless Connection

1. Make sure your phone is connected to a Wi-Fi source. Please note that the 360° HD Wi-Fi Camera does not support 5G Wi-Fi or Wi-Fi names with special characters (only letters and numbers are permitted).
2. Connect the included micro SD cable to power the device. The device should beep twice. If the device does not beep, insert the included metal key (or a paperclip) into the Reset slot for 1-2 seconds. If the device still does not beep, turn the camera off and on again.
3. Click the plus symbol "+" in the upper right-hand corner.
4. Choose "Smart Wireless Mode"
5. Enter the Wi-Fi password and click "next" when you hear the device beep.
6. When you hear "Camera Ready", you can name your camera and press save. Your camera is set up and ready to use.





Step 4: Connecting the Camera Using a Cable

1. Ensure that the Wi-Fi that your phone is connected to is in the same local area network as what your camera is plugged into.
2. Select "Wire Mode". Allow the device to search for and sync with your phone.
3. When you hear "Camera Ready", you can name your camera and press save. Your camera is set up and ready to use.



Main Functions



- | | | |
|--|----------------------------------|--------------------------------|
| 1. Alarm function | 4. Settings | 8. Record video |
| 2. Disconnect the camera | 5. Mute/Unmute | 9. Change video quality |
| 3. Share camera access to other accounts (up to 5) | 6. Take a photo (saves to phone) | 10. Set automatic angle timers |
| | 7. Hold to talk | |


Additional Functions

• Moving the Camera

Swipe the camera feed around to move the camera. If you've already taken a panoramic image, it will appear below the video stream. You can click on different points to move the camera to that point instantly. You can also pinch to zoom in, though this will not be saved in photo/video recording.

• Panoramic Image Stitching


1. Press to create a panoramic image.
2. Press "Try it Out".
3. The camera will automatically rotate to capture 15 pictures and stitch them together into one image.



• Sharing the Camera


You can share your camera with up to 5 other people. Click the button, click the plus "+" icon, and enter the email address they used to register their account. They will now have access to the camera and can even move the camera around.

Note: They must have the app installed on their phone to view the camera.



• Set Automatic Angle Timers

If you want to automatically set viewing angles throughout the day (perhaps you would like to move the camera angle from the door to the playroom when your children get home), set the position that you'd like to record, click , then set the time you'd like the camera to move. You can set multiple angles according to your schedule.



• Motion Detection Alarm

You can enable motion detection alerts to notify you of movement in front of the camera. With this setting enabled, the second your camera detects a moving object, you will receive a notification. Video will be recorded on the micro SD card or on the cloud (if you have purchased that option). You can set the times that motion detection is enabled, as well as the sensitivity of detection. You can also choose whether or not the camera sounds an alarm when the motion detection is triggered.

Note: This requires a micro SD card. You must insert the micro SD card before powering up the camera for it to work.

• Mounting the Camera

The camera comes with screws and wall-mounting anchors. If you choose to mount your camera on the ceiling, you will need to go into the settings and change the shooting angle to record upside-down.

Troubleshooting

The video screen is black	Ensure that the network speed on the upper right corner of the monitoring screen is more than 10kbps. If not, try to get a better internet connection to solve this problem.
Video has no sound	Uninstall the app and re-install the latest version of the app.
microSD card not detected or not saving files	Please use a certified C10 high-speed SD card. If the problem persists, format the SD card on your computer, insert it before turning on the camera, and try again.
Camera does not connect	Ensure your internet connection is working. Unplug the camera and plug it in again, then try connecting the camera from the beginning.

Technical Specifications

Product Dimensions	9.5x9.5x14cm
Weight	230g
Color	White
Material	ABS